*Full Length Research Paper*

# **Optimization of plug utilized in lost circulation treatment while drilling**

## **Abdelkader Khiari 1 , Djemoi Merzoug 1 , Noureddine Gherraf 1 \*, Mourad Kourichi 2 and Noureddine Maza 1**

<sup>1</sup>Laboratoire des Ressources Naturelles et Aménagement des Milieux Sensibles, Larbi Ben M'hidi University, Oum el Bouaghi, 04000 Algeria.

<sup>2</sup>Laboratoire de génie de procédés, UKMO Ouargla University 30000 Algeria.

Accepted 15 October, 2010

The major problem of oil wells drilling is circulation lost that can occur near weak formations and before **well cementing. Conventional methods such as lost circulation material pills, cement plugs and dual** injection were used to combat different types of massive mud loss in spite of their small success rate **and high cost and risk. A different circulation treatment has been introduced to optimize plugging of loss zones by minimizing cost and time. It consists of combining InstanSeal (seal formation instantly) and cement to improve the mechanical performance of the system. InstanSeal-cement plugging fluid is a loose invert emulsion (water-in-oil) that gels rapidly in normal drilling operations after passing through** the drill bit nozzles resulting in a rigid direct emulsion (oil - in- water) which will be squeezed and penetrated into weak formations to seal it. It is the only gelling system that uses mechanical means as a **trigger mechanism. The present work aims to optimize the emulsion mechanism, the composition effect and the InstanSeal-cement as follows: (i) Introduce the InstanSeal-cement as an approach to cure massive losses where conventional methods fail. (ii) Analyze the evolution of InstanSeal-cement fluid by changing each product concentration. (iii) Find the proper emulsion of each kind of losses. (iv) Optimize the system according to the equipment taking into account the mixing energy. (v) Find the most effective formulation using mathematic models. (vi) The laboratory pre-checks will be taken as helping** data to minimize the failure risk. After the success results obtained from the yard test, the InstanSeal**cement proved that it is competent to cure massive losses by improving the success rate (80%). This economic success can be matched by reducing risks, achieving excellent results and decreasing drilling time through a critical section.**

**Key words:** InstanSeal, drilling fluid, circulation lost, optimization.

## **INTRODUCTION**

Drilling fluids, such as mud, are fluids used to drill a hole through the earth crust. They circulate down the rotating drill pipe through the bit and up the annular space between the pipe and the formation or steel casing; to the surface (Henry et al., 1983).

In many parts of the world specific techniques and methods are being implemented to combat massive mud loss and save the well in spite of their cost, time consumption and risk (Tailleur, 1963). Instanced-cement

is a ''patented circulation treatment'' which was developed as a solution to cure lost circulation problems while drilling when conventional methods fail. It is defined as a single fluid able to cure massive mud losses instantly by being pumped through the drill bit nozzles (www.connect.slb.com. \*Mark of Schlumberger, 1999).

This shear-sensitive plugging fluid was designed to gel rapidly after passing through the bottom hole assembly in normal operations, thus forming a solid mass. It is a gelling system which uses mechanical means as a trigger mechanism to develop its initial compressive strength but not to consolidate the formation. Before developing some gel strength, the plugging fluid maintains the rheology of the drilling fluid allowing its penetration into the loss zone

<sup>\*</sup>Corresponding author. E-mail: ngherraf@yahoo.com. Tel: 00213 77503 39 56.



**Table 1.** Some test samples.

where it actually stops and provides a permanent sealing.

#### **STANSEAL-CEMENT REACTION MECHANISM**

This plugging fluid is activated by mechanical means to give rigid gel that allows the lost circulation zone to be closed off quickly and continue drilling (David et al., 1999).

### **Definition**

InstanSeal-cement is a single reactive fluid which is based upon what is termed a " loose" invert emulsion that is (water - in - oil ) or " shear-sensitive'' invert emulsion. This is due of the degree of instability towards high shear forces. It consists of: oil emulsifier, bentonite, crosslinker, viscosifier, class G cement and water.

## **Functioning principal**

The shear activated gel consists of two phases -water and oil- emulsion. The internal phase of the loose plugging fluid (water) consists of a high polymer concentration (water soluble polymer) and the continuous phase (oil) contains a cross linker and cement. Upon exposing the fluid to high shear forces (pressure drop across small orifice) the loose invert emulsion undergoes very rapid deformation and flips to more stable direct emulsion (oil in water). Enough energy must be imparted to the system to invert the emulsion. This is accomplished by shearing the fluid with about 500 psi differential pressure at the drill bit.

#### **Reaction mechanism**

To provoke and initiate the emulsion inversion (the mechanical reaction between the reactive species) a minimum shear threshold must be achieved. When the loose invert emulsion is subjected to high shear forces,

the emulsion flips and results in a rupture that releases both the encapsulated cross linker and the cement from the oil phase to the new water continuous phase, allowing the cross linker to contact the polymer that triggers the gel, forms a solid mass and initiates the cross-linking reaction almost instantaneously. The final product is a rigid, robust, very hard, but plastic gel created in few minutes after passage through the bit.

The loose emulsion is maintained by a low concentration of an emulsifier. The surface of the cross linker is oil wet and remains in the oil phase. The high shear triggers a rupture in the interfacial membrane of the emulsion by making the large water droplets ruptured to give an emulsion containing more stable numerous and smaller diameter oil droplets. The interfacial tension between the two phases is maintained by the emulsifier (surfactant) that reduces the surface tension between the water droplets and the oil (Parvazinia and Nassehi, 2006).

## **Chemistry of cross linked gel**

The viscosifier is a water soluble polymer (polysaccharide) which has hydroxyl groups along its chain. In a specific pH region an oligomerisation is occurred by the creation of cross linked bond between hydroxyl groups and metallic polyvalent ions or other organic molecules.

The transfer of the cross linker into the high concentration polymer slurry is rapid. This is why this system (gelling time) is temperature independent http://www.slb.com/services/cementing/lost\_circulation/in stant seal.aspx. The instability of the loose emulsion is exploited to create the new technology.

#### **EXPERIMENTAL**

#### **Check ratio and interpretation**

Table 1 discusses the test sample and Table 2 discusses the manipulation observation. However, the other tests have been performed in a similar way.

**Table 2.** Manipulation observation.

<b>Test number</b>	<b>Observation</b>
	Good mixability and very viscous fluid, pH: 11.62, Gelling time: 7 s
2	Good mixability and less viscous fluid, pH: 11.65, Gelling time: 6 s
3	Difficult mixability, pH: 11.66, Gelling time: 5 s
4	Good mix ability, pH: 11.37, Gelling time: 65 min
5	Good mixability, pH: 11.67, Gelling time: 55 min
6	Acceptable mixability, pH: 11.69, Gelling time: 55 min.

**Table 3.** OWR effect.





**Figure 1.** OWR effect on pH.



**Figure 2.** OWR effect on gelling time.

## **RESULTS AND DISCUSSION**

#### **OWR (oil-water-ratio) effect**

Table 3 and Figures  $1 - 4$  discuss the OWR effect. The impact of the oil-water-ratio on the other parameters is



**Figure 3.** OWR effect on gel strength.



**Figure 4.** OWR effect on plastic viscosity.

less important except on the viscosity.

## **Emulsifier effect**

Table 4 and Figures 5 to 7 discusses the emulsifier effect.



**Table 4.** Emusifier effect.



**Emulsifier (ml)**

**Figure 5.** Emulsifier effect on rheology.



**Figure 6.** Emulsifier effect on gelling time.



**Figure 7.** Emulsifier effect on gel strength.

#### *Formulations with emulsifier = 5 ml*

5 ml as emulsifier concentration is enough to facilitate the mixing and create the emulsion. However; the gelling time obtained with this concentration is not adequate to cure losses. It is very short and it can prevent the InstanSeal-cement from the penetration into the loss zone to seal it. Therefore, to continue the study a high concentration of emulsifier is added with maintaining the same reference design.

#### *Formulations with emulsifier = 8 ml*

If the OWR is low the mix ability can not be easy because the water volume is high. High OWR leads to improve the gel strength which means that the InstanSeal-cement is hard. For a high OWR, the obtained pH value is not high

in comparison to that for low OWR. This means that the cross linker and cement are well protected in the oil phase (cross linking reaction is slow). The loose emulsion is more stable.

The slow release of the cement and the cross linker give a delayed gelling time. This is observed where OWR is high. High rheology property indicates the best transfer of the cement and the cross linker. This can be observed in the formulation where OWR is low. A reduced gelling time and an acceptable plastic viscosity with a better gel strength were observed with OWR: 25.0% and OWR: 75%. Therefore this ratio is chosen as the base ratio.

#### **Observations while checking**

For OWR 25% and OWR 75% the InstanSeal-cement cubic samples treated for 24 h in the curing chamber are deformable by applying a high finger pressure. This means that this formulation can be used as a plug to cure losses but it stays soft after 24 h from injecting.

#### **Interpretation**

For the formulation without emulsifier it was not observed any emulsion (bad mixing). But a high emulsifier concentration leads to an easier mixing. Increasing the emulsifier concentration delays the gelling time owing to the good curvature of this surfactant around the water droplets by minimizing the transfer of cross linker and cement from the oil phase to the water phase. This slow diffusion is the reason for getting a very long gelling time. The minimal transfer gives reduced values of rheology and pH. An exceeded concentration of emulsifier may prevent the InstanSeal-cement from setting (as it is shown in the last test where emulsifier  $= 8$  ml which gives more than three hours as a gelling time and makes the formulation useless.

The formulations leading to a short gelling time should not be prepared to cure losses (InstanSeal-cement can not penetrate into the loss zone) whereas a long one can cure minor losses.

The high concentration of emulsifier reduces the gel strength. It is also observed that the evolution of the gel strength between 4 and 24 h is not well developed. Therefore the operator can continue drilling before 24 h from pumping. This proves that the emulsifier has a slight effect on the gel strength.

#### **Emulsifier has a strong effect on the gelling time of the InstanSeal-cement**

#### *Bentonite effect*

Table 5 and Figures 8 and 9 discuss the effect of bentonite.







**Figure 8.** Bentonite effect on gelling time.



**Figure 9.** Bentonite effect on gel strength.







**Figure 10.** Cross linker effect on gelling time.



**Cross linker (grs)**

**Figure 11.** Cross linker effect on gel strength.

#### **Observations while checking and results interpretation**

Preparing formulation without bentonite gives an inconsistent emulsion. Thus the solids were sedimented at the bottom of the container and a very high quantity of

water was not absorbed. This proves that the bentonite is the water absorption responsible. The bentonite is an accelerator (gelling time is reduced by adding more bentonite). Thus the presence of solid particles provides another shear forces to the system. In the range of 15 - 25 g the bentonite could not reduce the gelling time less than 3 min. This means that it has a slight impact on the gelling time of the InstanSeal-cement. According to the charts built, it is noted that the bentonite has a slight impact on the gel strength since its increase results in a slight increase of the gel strength.

#### **The impact of the bentonite on the InstanSeal-cement behavior is too slight**

#### *Cross linker effect*

Table 6 and Figures 10 and 11 discuss the cross linker effect.

#### **Observations while checking and interpretation**

Preparing the InstanSeal-cement without cross linker gives a much delayed gelling time (several days). This means that the cross linking reaction (which results in the gelling) did not occur. The buffer resists the change in its hydrogen ion concentration; therefore the pH is maintained in the following range [1.45 -1.58].

The cross linker is a solid that gives additional shear energy to the system and reduces the gelling time. Adding more cross linker allows to more transfer of cross linker and cement. But using a very high amount may provoke an early gelling that prevents the InstanSealcement from the penetration into the loss zone.

#### **Fast release of cross linker results in a reduced gelling time and a high gel strength**

#### *Viscosifier effect*

Table 7 and Figures 12 -14 discuss the viscosifier effect.

#### *Observations while checking and interpretation*

Preparing the InstanSeal-cement without viscosifier gives a fluid with solids at the bottom of the container and a partial phase separation. It was also observed that this formulation did not accept any shearing (stays loose emulsion). The presence of the viscosifier that is cross linked after shearing induces of the cross linking reaction which means improving the gel strength. The gelling time is reduced and the viscosity increased by adding more viscosifier.

<b>Viscosifier</b>	<b>Plastic viscosity</b>	Gelling time	Gel	Strength (psi)
(m <sub>l</sub> )	(cp)	(min)	4 h	24 h
3	17.087	30	4.666	5.628
6	18.012	7	9.9972	10.139
6.5	18.012	5.5	13.377	13.884
7	21.014	4.5	13.651	14.276
7.5	24.017	4.5	13.879	14.386
8	27.019	3.5	14.545	15.997
9	36.025	3.5	15.029	17.304
10	40.001	3	15.279	18.464

**Table 7.** Viscosifier effect.



**Figure 12.** Viscosifier effect on gelling time.



**Figure 13.** Viscosifier effect on rheology.

**An increase of the viscosifier content has a little effect on the gelling time but improves the gel strength**

## *Cement effect*

Table 8 and Figures 15 -20 discuss the cement effect.



**Figure 14.** Viscosifier effect on gel strength.



## **Cement (grs)**

**Figure 15.** Cement effect on fluid volume.

## *Observations while checking and interpretation*

Preparing the InstanSeal without cement gives a very soft touch to the sample therefore introducing the cement to the classic InstanSeal-cement leads to improved gel

**Table 8.** Cement effect.





**Figure 16.** Cement effect on fluid density.



**Figure 17.** Cement effect on rheology.

strength. Using a very high amount of cement (more in 400 g) results in a difficult mixing and shearing. A  $\blacksquare$ amount of cement reduces the gelling time because the cement hydration contributes to the premature getting



**Cement (grs)**





**Figure 19.** Cement effect on gelling time.

through the release of divalent calcium ions. It leads also to high rheological properties (TY) that necessitates applying an initial pressure to facilitate the plugging fluid movement while pumping. Increasing the cement content leads to the increase of the gel strength and pH value (more than 12). This indicates that the reaction starts at

Barite (g)	<b>Density</b>	pH	Gelling time (min)	Gel	Strength (psi)
0	1.27	11.68	5	13.120	14.702
100	1.36	11.61	5	13.567	14.958
150	1.41	11.60	5	14.822	15.321
200	1.46	11.58	5	15.321	16.442
250	1.54	11.52	2	15.802	16.824
300	1.56	11.47	1.5	16.049	17.210
350	1.60	11.41		16.520	18.401
400	1.62	11.37	0.75	17.201	19.450

**Table 9.** Barite effect.



**Figure 20.** Cement effect on gel strength.



**Figure 21.** Barite effect on density.



**Figure 22.** Barite effect on pH.



**Figure 23.** Barite effect on gelling time.

the surface (before shearing) because the cement hydration provides a second source of cross linker. That is why the cement should be added just before the job. Adding cement increases the InstanSeal-cement volume. This must be taken into consideration because the job application is limited by the equipment.

**The cement leads to the better final mechanical properties and gains the compressive strength**

#### *Barite effect*

Table 9 and Figures 21 -24 discuss the barite effect.



**Figure 24.** Barite effect on gel strength.



**Figure 25.** Salts effect on fluid density.



**Figure 26.** Salts effect on rheology.



**Figure 27.** Salts effect on pH.



**Figure 28.** Salts effect on gelling time.



**Figure 29.** Salts effect on gel strength.

## *Observations while checking and interpretation*

Adding weighting agents to the InstanSeal-cement leads to higher rheological properties and improves the gel strength. This weighting agent (barite) can accelerate the gelling time because the solid particles provide additional shear energy to the system and slightly impair the release of the cross linker and cement. This is why the pH value is reduced while increasing the weighting agent amount. Adding more barite gives a high value of density that reduces the contamination between the InstanSealcement and the well bore drilling fluid. The barite improves the stability of the gel.

## *Salts effect*

Figures 25 -29 and Table 10 discuss the salts effect.



**Table 10.** Salt effect.

#### *Observations while checking and interpretation*

The salts increase the viscosity of the water. High amount of salt added to the water used to prepare the InstanSeal-cement can impair the cross linking reaction. This gives a reduced pH value, a delayed gelling time and weak gel strength.

#### **Conclusions**

(i) The resulting gel is robust in the initial phase and in the following days as the cement gains the compressive strength.

(ii) The cross linker must be released at a delayed rate to generate a suitable gelling time.

(iii) The gelling time can be increased or decreased by making the emulsion more or less shear sensitive.

(iv) The gelling time depends upon pressure and emulsifier concentration.

(v) The gelling time should be sufficient for fluids to enter the formation.

(vi) The InstanSeal cement requires follow-up with trying to mix with other additives to improve its feature and application range.

(vii) The salt is detrimental to the gel strength.

#### **REFERENCES**

- Henry CH, Darley George Robert Gray (1983). Composition and properties of drilling and completion fluids; 5<sup>th</sup> edition golf publishing company, Houston TX; pp. 2-19.
- Tailleur RJ (1963). 6th World Petroleum Congress. June pp. 19 26. Frankfurt am Main, Germany www.connect.slb.com. \*Mark of Schlumberger. 1999.
- David Quinn SPE, Schlumberger Dowell, Egil Sunde SPE (1999). Statoil A/S; and J. F. Baret. SPE. Schlumberger Dowell, Mechanism of a Novel Shear-Sensitive Plugging Fluid to Cure Lost Circulation. SPE International Symposium on Oilfield Chemistry. pp. 16-19, February. Houston, Texas.
- Parvazinia M, Nassehi V (2006). Study of shear thinning fluid flow<br>through highly permeable porous media, International through highly permeable porous media, Communications in Heat and Mass Transfer. 33(4):401-410
- http://www.slb.com/services/cementing/lost\_circulation/instant\_seal.asp x.